


TOP AND CONSOLE PARTS

ELECTRIC DRYER

For Models: WED9400SW0, WED9400SB0, WED9400ST0, (WED9400SZ0) (WED9400SU0)
 (White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS


For Models: WED9400SW0, WED9400SB0, WED9400ST0, (WED9400SZ0) (WED9400SU0)
 (White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	9	3936144	Plug, Terminal	24	W10012460	Detent Wheel (Service Only With Illus. 28)
	W10110850	Use & Care Guide	10	94613	Terminal	25	W10095960	Harness, Communication
	W10110638	Tech Sheet	11	3390647	Screw, 8-18 x 1/2	26	W10012820	Knob, Spring (2) (Service Only With Illus. 28)
	W10111226	Guide, Quick Start	12	W10112267	Foam-Seal	27		Knob, Control (Includes: Illus. 21)
2		Top	13	W10030070	Array, Power			
	8565021	White	14	3936150	Connector, 7-Circuit			
	8579997	Black	15	3395683	Connector, (Motor)			
	8519252	Biscuit	16	8281225	Screw, 8-18 x 1/2			
	W10114785	Ultimate Silver	17	2203186	Connector, 5-Circuit			
3	8579739	Harness, Main	18	W10031430	User Interface (Right)			
4		Panel, Console (Includes Items: 4,20,21,22,27,28)	19	W10121375	User Interface (Center) (Includes: Illus. 13)			
	W10116695	White	20	W10012430	Encoder-Wheel	28	280230	Encoder, Wheel Kit. (Includes Item: 23, 24, & 26)
	W10116698	Black	21	W10012440	Retainer-Snap	29	W10112268	Clip-Harness (4)
	W10116696	Biscuit	22	W10012410	Knob, Light Ring (Includes: Illus. 21)	30	3391018	Tie, Cable
	W10116699	White/Blue	23	W10012810	Rast, Wheel Holder (Service Only With Illus. 28)	31	W10117943	Badge
	W10116697	Ultimate Silver				32	W10110976	Cube-Cable
5	3394427	Clip, Harness						
6	W10006840	Bracket, Console (Includes No.12)						
7	353424	Connector, Sensor						
8	94614	Terminal						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: WED9400SW0, WED9400SB0, WED9400ST0, (WED9400SZ0) (WED9400SU0)
 (White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: WED9400SW0, WED9400SB0, WED9400ST0, (WED9400SZ0) (WED9400SU0)
 (White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8576583	Cover, Terminal Block	19	8574875	Assembly, Door Switch	41	W10110641	Board, Control
2	3390814	Screw, 8-18 x 3/8	20	690997	Tri Ring	42	98129	Screw, 6-20 x 1 1/16
3	697776	Screw, 10-32 x 5/8 (Ground)	21	8066115	Cover-Plate	43	3390647	Screw, 8-18 x 1/2
4	3397659	Block, Terminal	22	8529053	Ramp, Door	44	3387242	Seal, Front Panel
5	3394881	Switch, Broken Belt	23	W10118614	Seal, Door Switch	45	3393008	Screw, 10-16 x 1/2
6	3357011	Screw, 10-16 x 1/2 Panel, Side (L.H.)	24	W10139003	Panel, Side (R.H.) White	46	8519459	Clip, Toe Panel
7	W10138989	White		W10139010	Black	47	W10116271	Toe-Panel White
	W10138996	Black		W10139004	Biscuit		W10116273	Black
	W10138990	Biscuit		W10139009	Silver		W10116272	Biscuit
	W10138995	Silver	25	3389682	Space-Toe Panel		W10116277	Silver
8	3392100	Foot, Dryer	26	62825	Clip-S Type	48	W10133207	Panel, Rear
	279810	Foot – Optional (Extended Length Package Of 2) (Not Included)	27	8538263	Motor, Assembly 60 HZ.	49	343641	Screw, 10-16 x 1/2
9	660658	Clamp, Motor (2)	28	3398948	Wire, Jumper (Broken Belt Switch)	50	8519207	Base, Cabinet Front Panel
10	3387374	Spring, Idler	29	8578220	Pulley 60 HZ.	51	8578388	White
11	3389420	Retainer, Idler	30	3387610	Belt, Drive	8578936	Black	
12	697750	Plug, Multivent White	31	W10118470	Cover, Control Bracket	8577910	Biscuit	
	3388309	Black	32	3387118	Bracket, Motor	8578940	Silver	
	3388311	Biscuit	33	279393	Terminal Block Screw Kit (For Terminal Block)	52	696144	Strike, Door (2)
	8579115	Silver	34	49026	4" – 90° Elbow	53	90767	Screw, 8-18 x 3/8
13	3388672	Pulley Assembly	35	3407228	Power Cube	54	W10110990	Harness, Digital Interface
14	279318	Terminal, Brass & Tinned (3) (Includes Illus. 33)	36	8563747	Exhaust Pipe & Bracket			
15	8066120	Lever, Snap Switch	37	8563750	Exhaust Pipe (Short)			
16	3394081	Wire, Belt Switch	38	8563749	Exhaust Pipe (Long)			
17	W10128772	Sound Panel	39	3388674	Idler Bracket	55	279818	White
18	233520	Washer, Thrust	40	8563727	Bracket, Control	279820	Black	
						279925	Biscuit	
						280171	Ultimate Silver	


Optional Parts Not Included

Dryer Exhaust Kit (For Side & Bottom Venting)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: WED9400SW0, WED9400SB0, WED9400ST0, (WED9400SZ0) (WED9400SU0)
 (White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS


For Models: WED9400SW0, WED9400SB0, WED9400ST0, (WED9400SZ0) (WED9400SU0)
 (White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8575324	Shaft, R.H. Thread	16	W10001120	Nut, 3/8-16 (L.H.)	36	W10136369	Socket Assembly
2	3390647	Screw, 8-18 x 1/2	17	8520836	Bulkhead, Rear	37	697772	Wheel, Blower
3	3394984	Door, Lint Screen	18	3387459	Washer, Support	38	W10049370	Screen, Lint
4	3406653	Harness, Sensor	19	8575325	Shaft, L.H. Thread	39	3394986	Spring, Lint Screen Door
5	697354	Air Duct Assembly	20	W10121334	Washer	40	697770	Seal, Cover Plate
6	697813	Seal, Outlet Housing	21	8536973	Roller, Support	41	8299979	Grille, Outlet
7	697814	Seal, Drum Front	22	8563745	Exhaust Pipe	42	8577274	Thermistor
8	3934666	Nut, 3/8 x 16(R.H.)	23	3394985	Housing, Outlet	43	487909	Screw, 8-15 x 1/2
9	3392519	Thermal-Fuse (91°C)	24	8529007	Plug, Rear Bulkhead	44	8544362	Housing, Blower
10	3402841	Lens, Drum Light	25	W10113138	Complete Drum Assembly	45	8066168	Lint Duct Assembly
11	489463	Screw, 8-18 x 3/8	26	W10109200	Screw, 11-16 x 3/4	46	8544769	Housing-Slot Heater Box
12	8572105	Clip, Exhaust Pipe	27	697694	Seal, Drum	47	280148	Thermal Cut-Off (Includes Illus. 48)
13	8066208	Clip-Spring	28	695240	Screw, 8-18 x 1/2	48	8557403	Thermostat 295°F (146°C) (Hi-Limit)
14	8544771	Heater Element	29	8533971	Screw, 8-18 x 3/8	49	8544770	Housing-Tab Heater Box
15	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	30	8519221	Channel Bracket, Rear Bulkhead (2)	50	8066099	Bracket, Heater Box
			31	8571651	Bracket, Upper Rear Bulkhead	51	3387230	Screw, 10-16 x 1
			32	W10113136	Baffle, Drum	52	8544776	Flange-Heater Box
			33	3406124	Bulb, Light	53	8519245	Bulkhead, Front
			34	3387223	Electrode, Sensor			
			35	3977373	Bracket, Drum Light			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

**For Models: WED9400SW0, WED9400SB0, WED9400ST0, (WED9400SZ0) (WED9400SU0)
(White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)**



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Label-Hinge Hole Cover	8	3393008	Screw, 10-16 x 1/2	15	8579662	Seal, Window
	W10085210	White	9		Door Assembly (Outer)	16	W10048910	Screw-Plug
	W10085230	Silver		8579520	Chrome	17	8566254	Window
2	W10139920	Door Hinge Assembly		8579521	Gold	18	8580116	Pad-Handle
3	W10017850	Screw, 10-24 x 3/64		8579514	Blue	19		Tear-Drop Trim & Clip Assembly
4	9742177	Screw, 8-18 x 5/8	10	8578229	Door Assembly (Inner) (Includes Illus. 12 & 25)	W10099270		White
5	8578153	Cover-Hinge (L.H.) (Following Parts Not Included)	11	355515	Screw, 8-18 x 11/16	W10099310		Black
	8578152	Cover-Hinge (R.H.)	12	3398175	Door Catch Assembly (Upper)	W10099320		Biscuit
6	W10139457	Seal-Door	13	8519356	Retainer-Window (Upper)	W10099280		White/Blue
7		Handle-Ring & Pad Assembly	14	8519354	Retainer-Window (Lower)	W10099330		Silver
	W10048070	Chrome				20	W10074630	Door-Shield
	W10048080	Gold				21	8578157	Door Intermediate
	W10048010	Blue				22	8578156	Door Mask
						23	8578155	Door Screen
						24	3393258	Screw, 10-16 x 1/2
						25	690081	Door Catch Assembly

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: WED9400SW0, WED9400SB0, WED9400ST0, (WED9400SZ0) (WED9400SU0)
(White/Chrome) (Black/Chrome) (Biscuit/Gold) (White/Blue) (Ultimate Silver)

<u>Illus.</u>	<u>Part</u>	<u>No.</u>	<u>DESCRIPTION</u>
---------------	-------------	------------	--------------------

PAINT, TOUCH-UP (1/2oz.)

72017	White
72302	Black
4392899	Biscuit
8212605	Ultimate Silver

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
786020	Black
4392901	Biscuit
350938	Primer, Gray

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit (Uncut)
786302	Black (Uncut)

ACCESSORY PARTS

8529894	Kit, Hold Down
8541503	Kit, Stack Assembly
8579666A	Kit, Door Reversing
80047	Kit, Dryer Repair
8521957	Dry Rack